

INSTALLATION INSTRUCTIONS

SILVER BULLET "Tapered" Replacement Muffler For 07-08 HARLEY-DAVIDSON SOFTAIL DELUXE Model SM-160



WARNING PLEASE READ BEFORE INSTALLATION!

- Read all instructions thoroughly and confirm that all listed components are available for installation.
- Adding a free flowing exhaust systems may require rejetting of the carburetor. Lean carburetor settings are a major factor causing exhaust discoloration and potential engine damage.
- Samson® exhaust systems are designed to fit and work with OEM frames and motors.
- After installation thoroughly clean the new exhaust system before starting the motor.

REMOVAL PROCEDURE:

- Loosen the muffler clamp at the front of the muffler under the heat shield and set aside to be used on the new mufflers. Remove the bolts holding the mufflers to the mounting brackets.
- Slide the muffler off the bike.
- Repeat procedure on the other muffler.

CAUTION: WITH SOME EXHAUST DESIGNS GROUND CLEARANCE MAY BE REDUCED!

INSTALLATION PROCEDURE:

NOTE: Do not tighten connections when first installing the system. To ensure proper fit and alignment all bolts and bracket are tightened at the end of the installation.

- Slide the new muffler over the head pipe.
- Attach the end cap and bolt the muffler to the mounting bracket using the hardware included.
- Tighten the muffler clamp.
- Repeat procedure on the other muffler.
- Check all bolts after 100 miles.

**REMEMBER TO CLEAN THE PIPES
BEFORE STARTING THE BIKE!**

TOOLS REQUIRED:

- 5/16" Combination wrench
- 9/16" Combination wrench
- 1/2" Combination wrench
- Ratchet, 6" extension and 1/2" swivel socket

PARTS LIST:

Qty.	Description
1 ea	Left Muffler
1 ea	Right Muffler
4 ea	1/4-20 x 3/4" Hex cap screws
4 ea	1/4-20 Nylock nuts
4 ea	1/4" Flat washers

